

INSTALLATION

1. Perimeter control will be placed at locations indicated on plans and in a manner as directed by the Engineer or Manufacturer.
2. Perimeter control should be installed parallel to the base of the slope or other disturbed area. In challenging conditions (i.e., 2:1 slopes), a second perimeter control shall be constructed at the top of the slope, or staking may be increased.
3. Effective Soxh height in the field should be as follows: 5" diameter Soxh = 4" high; 8" diameter Soxh = 6.5" high; 12" diameter Soxh = 9.5" high; 18" diameter Soxh = 14.5" high; 24" diameter Soxh = 19" high.
4. Stakes should be installed through the middle of the perimeter control on 10 ft (3m) centers, using 2 in (50mm) by 2 in (50mm) by 3 ft (1m) wooden stakes. 5" diameter Soxh may use 1" (25 mm) x 1" (25 mm) x 18" (0.5 m) wooden stakes. In the event staking is not possible, i.e., when perimeter control is used on pavement, heavy concrete blocks shall be used behind the perimeter control to help stabilize during rainfall/runoff events.
5. Staking depth for sand and silt loam soils shall be 12 in (300mm), and 8 in (200mm) for clay soils.
6. Straighten or position the Soxh as needed on the ground, ensuring there is good ground contact and no void spaces under the Soxh.
7. Do not drag Soxh across rough surfaces. If dragging across a



rough surface is necessary, place a barrier such as plastic or a tarp under Soxh to prevent tearing.

8. Loose compost may be backfilled along the upslope side of the perimeter control, filling the seam between the soil surface and the device, improving filtration and sediment retention.
9. If the perimeter control is to be left as a permanent filter or part of the natural landscape, it may be seeded at time of installation for establishment of permanent vegetation. The Engineer will specify seed requirements.


MAINTENANCE & DISPOSAL

1. The contractor shall remove sediment at the base of the upslope side of the perimeter when accumulation has reached 1/2 of the effective height of the sock, or as directed by the Engineer. Alternatively, a new perimeter control sock can be placed on top of and slightly behind the original one creating more sediment storage capacity without soil disturbance.
2. Perimeter control shall be maintained until disturbed area above the device has been permanently stabilized and construction activity has ceased.
3. The FilterMedia will be dispersed on site once disturbed area has been permanently stabilized, construction activity has ceased, or as determined by the Engineer.

FILTREXX[®] SILT SOXX[™]



COMPOST SOCK CONNECTION/ATTACHMENT DETAIL



- NOTES:
1. ALL MATERIAL TO MEET FILTREXX[®] SPECIFICATIONS.
 2. SILT SOXX[™] FILL TO MEET APPLICATION REQUIREMENTS.
 3. COMPOST MATERIAL TO BE DISPERSED ON SITE, AS DETERMINED BY ENGINEER.

Refer to Design Specification for complete application, design, installation, maintenance, and removal documentation.